

## Diesel Torque - Fitting Instructions for 81KW engines

The tuning box is fully encapsulated and water resistant. However please ensure that it is securely fastened back to the engine bracket - excessive vibration or shock will ultimately damage it's performance.

**1.** Golf/Jetta/Skoda/Seat etc - transversley mounted 81kw engines - remove engine cover to access wiring connector shown in photo 2.

**2.** With engine cover removed - on the front of the engine just to the rear of the fuel pump you will see a large 8 or 10 pin loom connection - with a bracket retaining it to the engine.



**4.** Place the tuning box between the unplugged connectors and plug the loom ends back into the tuning box.

**3.** Just pull the connector from the bracket vertically. Then struggle with the lock tab and unplug the connector -

- 5.** The box will clip back into the engine bracket with some encouragement..then tie wrap to ensure that it cannot move or vibrate.
- 6.** After fitting, test drive the car. The effect of the box will differ from car to car in it's 'out of the box' state. The jumpers on the box are there to set the box up to suit your own car.

FOR PASSAT, AUDI A4, A6 ETC WITH LOGITUDINALLY MOUNTED ENGINE - THE SAME INSTRUCTIONS APPLY - BUT THE UNIT WILL THEN BE ON THE PASSENGER SIDE OF THE ENGINE.